



# Hill Laboratories

TRIED, TESTED AND TRUSTED

R J Hill Laboratories Limited  
1 Clyde Street Hamilton 3216  
Private Bag 3205  
Hamilton 3240 New Zealand

T 0508 HILL LAB (44 555 22)  
T +64 7 858 2000  
E mail@hill-labs.co.nz  
W www.hill-laboratories.com

Page 1 of 1

|                 |   |                          |                 |      |
|-----------------|---|--------------------------|-----------------|------|
| <b>Client:</b>  | Westervelt Honey Limited  | <b>Lab No:</b>           | 1734862         | SPV1 |
| <b>Contact:</b> | Chris Bowman<br>C/- Westervelt Honey Limited<br>PO Box 1941<br>Taupo 3351 | <b>Date Received:</b>    | 06-Mar-2017     |      |
|                 |   | <b>Date Reported:</b>    | 13-Mar-2017     |      |
|                 |   | <b>Quote No:</b>         | 63162           |      |
|                 |   | <b>Order No:</b>         | SORD1799        |      |
|                 |   | <b>Client Reference:</b> |                 |      |
|                 |   | <b>Submitted By:</b>     | Gabriela Dawson |      |

## Sample Type: Honey

| Sample Name:             |         | WHB1208<br>28-Feb-2017 | WHB1209<br>28-Feb-2017 | WHB1210<br>28-Feb-2017 |   |   |
|--------------------------|---------|------------------------|------------------------|------------------------|---|---|
| Lab Number:              |         | 1734862.1              | 1734862.2              | 1734862.3              |   |   |
| Aerobic Plate Count 35°C | cfu / g | 190 #1                 | 50 #1                  | 230 #1                 | - | - |
| Yeasts                   | cfu / g | < 50 #1                | < 50 #1                | < 50 #1                | - | - |
| Moulds                   | cfu / g | < 50 #1                | < 50 #1                | < 50 #1                | - | - |
| Yeasts & Moulds          | cfu / g | < 50                   | < 50                   | < 50                   | - | - |

## Analyst's Comments

#1 Statistically estimated count based on the theoretical countable range for the stated method.

## SUMMARY OF METHODS

The following table(s) gives a brief description of the methods used to conduct the analyses for this job. The detection limits given below are those attainable in a relatively clean matrix. Detection limits may be higher for individual samples should insufficient sample be available, or if the matrix requires that dilutions be performed during analysis.

| Sample Type: Honey       |  |                         |           |
|--------------------------|--|-------------------------|-----------|
| Test                     | Method Description   | Default Detection Limit | Sample No |
| Aerobic Plate Count 35°C | Count on APC Petrifilm, Incubated at 35°C for 48 hours. Analysed at Hill Laboratories - Microbiology; 101C Waterloo Road, Christchurch. APHA 8.82 5 <sup>th</sup> Ed.            | 10 cfu / g              | 1-3       |
| Yeasts & Moulds          | Spread plate, Count on DRBC agar, Incubated at 22-25°C for 5 days. Analysed at Hill Laboratories - Microbiology; 101C Waterloo Road, Christchurch. APHA 21.5 5 <sup>th</sup> Ed. | 50 cfu / g              | 1-3       |

These samples were collected by yourselves (or your agent) and analysed as received at the laboratory.

Samples are held at the laboratory after reporting for a length of time depending on the preservation used and the stability of the analytes being tested. Once the storage period is completed the samples are discarded unless otherwise advised by the client.

This report must not be reproduced, except in full, without the written consent of the signatory.

Lisa McCabe BAppSc  
Team Leader - Microbiology



**IANZ**  
ACCREDITED LABORATORY

This Laboratory is accredited by International Accreditation New Zealand (IANZ), which represents New Zealand in the International Laboratory Accreditation Cooperation (ILAC). Through the ILAC Mutual Recognition Arrangement (ILAC-MRA) this accreditation is internationally recognised. The tests reported herein have been performed in accordance with the terms of accreditation, with the exception of tests marked \*, which are not accredited.





# Hill Laboratories

TRIED, TESTED AND TRUSTED

R J Hill Laboratories Limited  
1 Clyde Street Hamilton 3216  
Private Bag 3205  
Hamilton 3240 New Zealand

T 0508 HILL LAB (44 555 22)  
T +64 7 858 2000  
E mail@hill-labs.co.nz  
W www.hill-laboratories.com

Page 1 of 1

|                 |                              |                          |                 |      |
|-----------------|------------------------------|--------------------------|-----------------|------|
| <b>Client:</b>  | Westervelt Honey Limited     | <b>Lab No:</b>           | 1734207         | SPv1 |
| <b>Contact:</b> | Chris Bowman                 | <b>Date Received:</b>    | 03-Mar-2017     |      |
|                 | C/- Westervelt Honey Limited | <b>Date Reported:</b>    | 09-Mar-2017     |      |
|                 | PO Box 1941                  | <b>Quote No:</b>         | 63162           |      |
|                 | Taupo 3351                   | <b>Order No:</b>         | SORD1799        |      |
|                 |                              | <b>Client Reference:</b> |                 |      |
|                 |                              | <b>Submitted By:</b>     | Gabriela Dawson |      |

## Sample Type: Honey

| Sample Name:                          | WHB1208<br>28-Feb-2017 | WHB1209<br>28-Feb-2017 | WHB1210<br>28-Feb-2017 |       |   |
|---------------------------------------|------------------------|------------------------|------------------------|-------|---|
| Lab Number:                           | 1734207.1              | 1734207.2              | 1734207.3              |       |   |
| C-4 Sugars Analysis                   |                        |                        |                        |       |   |
| $\delta^{13}\text{C}$ Honey (Whole)   | ‰                      | -26.0                  | -25.3                  | -26.7 | - |
| $\delta^{13}\text{C}$ Honey (Protein) | ‰                      | -26.6                  | -26.6                  | -26.9 | - |
| Difference (Whole - Protein)          | ‰                      | 0.6                    | 1.2                    | 0.2   | - |
| C-4 Sugar Content                     | %                      | 3.6                    | 7.4                    | 0.9   | - |

## Analyst's Comments

### Samples 1-3 Comment:

### C-4 Sugar Content:

As reported in AOAC method 998.12, pure honey (free of corn or cane sugars) with an exception of a few unusual varieties, yields a C-4 Sugar Content value of less than or equal to 7%. Some unusual varieties may slightly exceed this value, but will have a  $\delta^{13}\text{C}$  for honey which is in the normal range (more negative than -24.0‰).

## SUMMARY OF METHODS

The following table(s) gives a brief description of the methods used to conduct the analyses for this job. The detection limits given below are those attainable in a relatively clean matrix. Detection limits may be higher for individual samples should insufficient sample be available, or if the matrix requires that dilutions be performed during analysis.

| Sample Type: Honey                |   |                         |           |
|-----------------------------------|---|-------------------------|-----------|
| Test                              | Method Description  | Default Detection Limit | Sample No |
| C-4 Sugars Analysis (AOAC Method) | Methodology was performed in accordance with AOAC Official Method 998.12 (Revised First Edition 2013), C-4 Plant Sugars in Honey, using Internal Standard Stable Carbon Isotope Ratio Analysis (ISCIRA).<br><br>All isotope ratios are reported as 'per mil' i.e. parts per thousand (‰), relative to the international standard for Carbon, VPDB.<br><br>Analysis performed at Hill Laboratories - Food & Bioanalytical Division, Waikato Innovation Park, Ruakura Lane, Hamilton. | -                       | 1-3       |

These samples were collected by yourselves (or your agent) and analysed as received at the laboratory.

Samples are held at the laboratory after reporting for a length of time depending on the preservation used and the stability of the analytes being tested. Once the storage period is completed the samples are discarded unless otherwise advised by the client.

This report must not be reproduced, except in full, without the written consent of the signatory.

Helen McGowan BSc (Tech)  
Senior Laboratory Technician - Food & Bioanalytical





|                 |   |                          |                 |      |
|-----------------|---|--------------------------|-----------------|------|
| <b>Client:</b>  | Westervelt Honey Limited  | <b>Lab No:</b>           | 1734181         | SPv1 |
| <b>Contact:</b> | Chris Bowman<br>C/- Westervelt Honey Limited<br>PO Box 1941<br>Taupo 3351 | <b>Date Received:</b>    | 03-Mar-2017     |      |
|                 |   | <b>Date Reported:</b>    | 07-Mar-2017     |      |
|                 |   | <b>Quote No:</b>         | 63162           |      |
|                 |   | <b>Order No:</b>         | SORD1799        |      |
|                 |   | <b>Client Reference:</b> |                 |      |
|                 |   | <b>Submitted By:</b>     | Gabriela Dawson |      |

## Sample Type: Honey

|                     |             |             |             |  |  |
|---------------------|-------------|-------------|-------------|--|--|
| <b>Sample Name:</b> | WHB1208     | WHB1209     | WHB1210     |  |  |
|                     | 28-Feb-2017 | 28-Feb-2017 | 28-Feb-2017 |  |  |
| <b>Lab Number:</b>  | 1734181.1   | 1734181.2   | 1734181.3   |  |  |

## Individual Tests

|                             |                     |     |      |     |   |   |
|-----------------------------|---------------------|-----|------|-----|---|---|
| Leptosperin*                | mg/kg               | 540 | 710  | -   | - | - |
| NPA (Non Peroxide Activity) | % Phenol Equivalent | 9.9 | 13.0 | 3.0 | - | - |

## 3-in-1 Honey Analysis

|                               |       |       |       |    |   |   |
|-------------------------------|-------|-------|-------|----|---|---|
| Dihydroxyacetone              | mg/kg | 1,070 | 1,340 | 84 | - | - |
| 5-hydroxymethylfurfural (HMF) | mg/kg | 14.8  | 25    | 22 | - | - |
| Methylglyoxal                 | mg/kg | 256   | 405   | 36 | - | - |

## Tutin Analysis in Honey (Individual Samples)

|  |           |      |       |         |   |   |
|--|-----------|------|-------|---------|---|---|
| Tutin  | mg/kg     | 0.36 | 0.024 | < 0.010 | - | - |
| MRL as per Tutin in Honey Food Standard 2016 | mg/kg     | 0.70 | 0.70  | 0.70    | - | - |
| Tutin Result Evaluation                      | Pass/Fail | PASS | PASS  | PASS    | - | - |

## Analyst's Comments

### Sample 3 Comment:

NPA results less than 5 are estimated from extrapolation of the correlation curve and are indicative only.

## SUMMARY OF METHODS

The following table(s) gives a brief description of the methods used to conduct the analyses for this job. The detection limits given below are those attainable in a relatively clean matrix. Detection limits may be higher for individual samples should insufficient sample be available, or if the matrix requires that dilutions be performed during analysis.

| Sample Type: Honey          |  |                         |           |
|-----------------------------|--|-------------------------|-----------|
| Test                        | Method Description   | Default Detection Limit | Sample No |
| 3-in-1 Honey Analysis       | Water extraction, derivatisation, UPLC-UV analysis (dihydroxyacetone, 5-hydroxymethylfurfural, methylglyoxal). Analysis performed at Hill Laboratories - Food & Bioanalytical Division, Waikato Innovation Park, Ruakura Lane, Hamilton.   | 1.0 - 10 mg/kg          | 1-3       |
| Leptosperin*                | Aqueous extraction, dilution, analysis by LC-MS/MS.  | 15 mg/kg                | 1-2       |
| NPA (Non Peroxide Activity) | NPA is calculated from methylglyoxal using a correlation curve based on published data for NPA and the primary active ingredient, methylglyoxal. (1,2)<br>Analysis performed at Hill Laboratories - Food & Bioanalytical Division, Waikato Innovation Park, Ruakura Lane, Hamilton.<br><br>(1) Isolation by HPLC and characterisation of the bioactive fraction of New Zealand manuka (Leptospermum scoparium) honey. C. J. Adams, et al. Carbohydrate Research 343 (2008) 651-659.<br>(2) Corrigendum to "Isolation by HPLC and characterization of the bioactive fraction of New Zealand manuka (Leptospermum scoparium) honey" [Carbohydr. Res. 343 (2008) 651]. C. J. Adams, et al. Carbohydrate Research 344 (2009) 2609. | 1.0 % Phenol Equivalent | 1-3       |



| Sample Type: Honey      |  |                         |           |
|-------------------------|--|-------------------------|-----------|
| Test                    | Method Description   | Default Detection Limit | Sample No |
| Tutin Analysis in Honey | <p>Acidified acetonitrile/water extraction, analysis by LCMSMS. Analysis performed at Hill Laboratories - Food &amp; Bioanalytical Division, Waikato Innovation Park, Ruakura Lane, Hamilton.<br/><b>RLP Official Test 8.42</b></p> <p><u>Tutin Result Evaluation (PASS/FAIL)</u><br/>The PASS/FAIL result is based on comparison of the tutin result with the "Food Standard: Tutin in Honey (2016)". A result that falls at or BELOW the maximum permitted tutin level will give a PASS result. A result that falls ABOVE the maximum permitted tutin level will give a FAIL result.</p> <p><u>Individual Sample Testing Recommended?</u><br/>Where a tutin result for a composited sample is above the maximum permitted level, it is recommended that the individual samples are retested. Please contact the laboratory to arrange for individual sample retesting.</p> | -                       | 1-3       |

These samples were collected by yourselves (or your agent) and analysed as received at the laboratory.

Samples are held at the laboratory after reporting for a length of time depending on the preservation used and the stability of the analytes being tested. Once the storage period is completed the samples are discarded unless otherwise advised by the client.

This report must not be reproduced, except in full, without the written consent of the signatory.

Shaun Clay BSc  
Senior Technologist - Food and Bioanalytical